

How to attach the OBD damper to the diffuser.



You will be provided with a baggie of clips that will be used to attach the OBD damper to the collar of the diffuser frame.

** Please have a small hammer handy to tap these clips onto the collar.



The flanges of the damper will fit **inside** the collar and be held in place by the clips.



Place each clip onto the collar with the open side of the clip inside the collar. This is where the flange of the damper will slide into.

Flange of damper inserted here.

Once you have the flanges of the damper fitted inside each clip, gently tap with your hammer the top of the frame of your OBD to force the flanges into the clips.

Make sure they are all the way inserted. The damper will then be held in place firmly.

